

VO20

ASSEMBLY INSTRUCTIONS & DIMESNION



LeisureMod

Phone: (201) 429-7715

Email: Info@LeisureMod.com




VO20


ASSEMBLY INSTRUCTIONS & DIMESNION




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before assembling.



Unless instructed, do not fully tighten screws until the item is fully assembly.



Retain these instructions for future reference.



Do not discard any of the packaging until you have checked that you have all the parts and the pack of fixings.

LeisureMod

Phone: (201) 429-7715

Email: Info@LeisureMod.com





WARNING! TO REDUCE THE RISK OF SERIOUS INJURY, READ THE FOLLOWING SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND USING THE PRODUCT.

Please read and understand this entire manual before attempting to assemble, operate, or install the product.

Any assembly or maintenance of the product must be carried out by adults only.

Some parts may contain sharp edges. Wear protective gloves if necessary.

To prevent damage, place all parts on a level surface during assembly. Add a layer of protective surface if needed.

Due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken when assembling and handling the product in order to prevent the paint from being scratched.

TOOLS REQUIRED



2 person

NOTE:

To avoid damage, ensure screws are hand tightened.

DO NOT USE POWER TOOLS TO ASSEMBLE YOUR UNIT.

NOTE:

Philips head screw driver is required in the assembly process. However, manufacturer does not provide this item. Quantities shown are for one chair.

LeisureMod

Phone: (201) 429-7715

Email: Info@LeisureMod.com



ASSEMBLY INSTRUCTIONS








ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the seller immediately.
2. This product is for home use only and not intended for commercial establishments.

PARTS CHECKLIST

① Base	② GasColumn	③ Mechanism
		
 X5		
④ Armrest	⑤ Back	⑥ Seat
 X2		

LeisureMod

Phone: (201) 429-7715

Email: Info@LeisureMod.com



ASSEMBLY INSTRUCTIONS










ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the seller immediately.
2. This product is for home use only and not intended for commercial establishments.

PARTS CHECKLIST

1		6*25mm x4
2		6*20mm x2
3		8*16mm x3
4		6*30mm x2
5		x4
6		x4
7		6*16mm x8
8		x4
9		x1

LeisureMod

Phone: (201) 429-7715


Email: Info@LeisureMod.com




VO20

ASSEMBLY INSTRUCTIONS & DIMESNION

STEP 1



STEP 2



LeisureMod

Phone: (201) 429-7715


Email: Info@LeisureMod.com



VO20

ASSEMBLY INSTRUCTIONS & DIMESNION

STEP 3



STEP 4



LeisureMod

Phone: (201) 429-7715

Email: Info@LeisureMod.com



VO20

ASSEMBLY INSTRUCTIONS & DIMESNION

STEP 5



LeisureMod

Phone: (201) 429-7715

Email: Info@LeisureMod.com



Overall Height - Top to Bottom	46.85-49.21 in.
Overall Width - Side to Side	25.39 in.
Overall Depth - Front to Back	28.34 in.
Minimum Overall Height - Top to Bottom	46.85 in.
Maximum Overall Height - Top to Bottom	49.21 in.
Seat Height - Floor to Seat	17.72-20.07 in.
Seat Width - Side to Side	20.47 in
Seat Depth - Front to Back	20.47 in
Minimum Seat Height - Floor to Seat	17.72 in.
Maximum Seat Height - Floor to Seat	20.07 in.
Minimum Seat Depth - Front to Back	20.47 in.
Maximum Seat Depth - Front to Back	20.47 in.
Seat Cushion Thickness	2.95 in.
Headrest Height - Top to Bottom	5.90 in.
Chair Back Height	23.22 in.
Arm Height - Floor to Arm	24.40-26.77 in.
Armrest Width - Side to Side	2.75 in.
Armrests Min Height - Floor to Armrest	24.40 in.
Armrests Max Height - Floor to Armrest	26.77 in.
Chair Back Height - Seat to Top of Back	23.22 in.
Chair/Stool Back Width - Side to Side	20.07 in.

LeisureMod

Phone: (201) 429-7715


Email: Info@LeisureMod.com



Its Ready !!!

VO20

ASSEMBLY INSTRUCTIONS & DIMENSION



LeisureMod

Phone: (201) 429-7715

Email: Info@LeisureMod.com



Its Ready !!!